


# FunSicle®

# Rainbow FunSpray Splash Mat



## User Guide



Sign up for future  
offers and discounts.  
Scan the QR Code.

# Welcome!

Congratulations on your new Funsicle Rainbow FunSpray Splash Mat. This guide will walk you through everything from setting up to maintaining and enjoying your splash mat.

As always, we're here to help. For any issues, questions, or extra support, visit [funsicle.com/support](https://funsicle.com/support), or contact Customer Service at 888-670-4FUN (888-670-4386) or [HelloFun@Funsicle.com](mailto:HelloFun@Funsicle.com).

## Safety Guidelines

### IMPORTANT SAFETY INSTRUCTIONS

When installing and using this product, basic safety precautions should always be followed, including the following:


### READ AND FOLLOW ALL INSTRUCTIONS

**Keep this User Guide for future reference. Failure to follow these warnings and instructions can result in serious injury or death to users, especially children.**

#### Warnings

#### ⚠ WARNING

##### PREVENT DROWNING!



- Closely watch children who are in or near this splash mat.
- Children under 5 are at highest risk for drowning.
- Do not leave child unattended while in use.
- Use only under competent supervision.
- Empty the splash mat or prevent access when not in use.



##### NO DIVING!

You can break your neck and be paralyzed.

Empty the splash mat when not in use to prevent children from gaining unauthorized access and drowning.

Read and follow all safety information and assembly instructions in the User Guide.

### SAFETY CARE FOR CHILDREN

- Prevent Young Children from Drowning:
  - a. Install fencing or approved barrier around all sides of splash mat.
  - b. Children under 5 years old are at highest risk for drowning.
  - c. Closely watch children who are in or near this splash mat.
  - d. Empty splash mat or prevent access when not in use.
- Prevent Young Children from Gaining Access to Splash Mat:
  - a. Position furniture away from the splash mat so that children cannot climb and gain access to the splash mat.
  - b. When leaving the splash mat, remove floats and toys from the splash mat that might attract a child.
- Assign an adult to be responsible for watching children in the splash mat. Give this person a "water watcher" tag and ask that they wear it the entire time they are in charge of supervising children in

the splash mat. If they need to leave for any reason, ask this person to pass the “water watcher” tag and the supervision responsibility to another adult. **For replacement of the water watcher tag, visit [funsicle.com](http://funsicle.com)**

- Splash mat presents a drowning hazard even during filling and draining of the splash mat. Maintain constant supervision of children and do not remove any safety barriers until the splash mat is completely empty and stowed away.
- Drowning occurs silently and quickly and can occur in as little as 2 inches (5 cm) of water.
- Keep children in your direct sight, stay close, and actively supervise them when they are in or near this splash mat and when you are filling and emptying this splash mat.
- When searching for a missing child, check the splash mat first, even if the child is thought to be in the house.
- Empty splash mat completely after each use, and store the splash mat in such a way that it does not collect water from rain or any other source.
- Keep unsupervised children from accessing the splash mat by installing fencing or other approved barriers around all sides of the splash mat. State or local laws or codes may require fencing or other approved barriers. Check state or local laws and codes before setting up splash mat.
- See latest published edition of CPSC Pub. No. 362 found at [poolsafely.gov](http://poolsafely.gov).
- Do not leave toys inside splash mat when finished using the splash mat, since toys and similar items might attract a child to the splash mat. Position furniture (e.g. tables, chairs) away from splash mat, so that children cannot climb on it to gain access to the splash mat. After using splash mat, remove water to a level of 1/2 inches (1 cm) or less.

## DIVING RISK

Do not dive into this Splash Mat. Diving into shallow water can result in a broken neck, paralysis, or death.

## ELECTROCUTION RISK

Keep all electrical lines, radios, speakers, and other electrical appliances away from the splash mat. Do not place splash mat near or under overhead electrical lines.

## FIRST AID

Keep a working phone and a list of emergency numbers near the splash mat. Become certified in cardiopulmonary resuscitation (CPR). In the event of an emergency, immediate use of CPR can make a life-saving difference.

## WARNING

- This splash mat must be assembled on a smooth and level site of firm soil that is free of stones, gravel, sticks, black-top or other oil based compounds.
- Do not install splash mat on a wooden deck or any type of wooden surface.
- Do not install the splash mat on a slope or inclined surfaces, on soft or loose soil conditions (e.g. sand or mud), or on an elevated surface such as a deck, platform or balcony, which may collapse under the weight of the filled splash mat.
- This splash mat should be set up so that it complies with local safety and building codes. The splash mat is to be assembled by an adult. Care should be taken in the unpacking and assembly of the splash mat. This splash mat may contain accessible potentially hazardous sharp edges or sharp points that are a necessary part of the function of the splash mat.
- **CAUTION:** Keep out of baby's reach.
- **WARNING:** Use only under supervision.
- The product must be assembled and disassembled by adult.
- **WARNING:** For domestic use only.

## Consumer Awareness Booklets

Contact U.S. Consumer Product Safety Commission (CPSC) at [poolsafely.gov](http://poolsafely.gov) for publication "Safety Barrier Guidelines for Residential Pools". Contact The Association of Pool & Spa Professionals (APSP, formerly NSPI) at [www.APSP.org](http://www.APSP.org) for these publications: "The Sensible Way to Enjoy Your Above-ground/On-ground Swimming Pool", "Children Aren't Waterproof", "Pool and Spa Emergency Procedures for Infants" and "Layers of Protection".



**Danger:** Competent supervision and knowledge of the safety requirements is the only way to prevent drowning or permanent injury in the use of this product. Never leave young children unattended.

# SAVE THESE INSTRUCTIONS

# Setting Up Your Splash Mat

---

1. Locate a clean area free of stones or other sharp objects to place the splash mat.
2. Connect the splay mat to a standard garden hose:
  - a. If your standard garden hose does not come with a Quick-Connect mechanism, simply tighten the Threaded Water Hose Connector to a standard garden hose.
  - b. For standard garden hose with a Quick-Connect mechanism, tighten the mechanism between the Threaded Water Hose Connector and the standard garden hose.



Turn the water on slowly, and adjust to your desired spraying pressure by rotating the tap (if applicable).

**IMPORTANT:** When filling water into the splash mat, make sure the splash mat is kept placed flat without any twists. This could avoid any abnormal water pressure that may damage the splash mat.

## Emptying Your Splash Mat

---

Lift up one side of the splash mat to empty the water.

### NOTES:

- Splash mat should be cleaned with mild soap and lukewarm water only.
- Make sure splash mat is completely dry before storing to help prevent mildew from forming.
- Store all parts in a dry, temperature-controlled area where temperatures do not go below 32°F or above 125°F.
- Use a small patch kit to repair punctures or holes in splash mat.

## Repairing Your Splash Mat

---

1. Use a mix of liquid dish soap and water in a spray bottle, and spray over suspicious areas. Any leak will produce bubbles that will pinpoint the location of the leak.
2. Thoroughly clean the area surrounding the leak to remove any dirt or grime.
3. Cut a piece of repair patch (included) with a margin of 0.8 inches (2 cm) larger than the damaged area, rounding the corners with scissors.
4. Place the patch over the center of the leak, press down firmly, and squeeze out all air bubbles to the edges. You may want to put a weight on top to keep it in place.
5. Do not use for one hour after patching.

### NOTE:

If the patch does not hold, you can use the patch with silicone or polyurethane-based glue designed for repairing camping mats, tents or shoes. Consult your local household/camping supply stores, and follow the instructions of the glue you have chosen.

[This page is intentionally left blank.]

[This page is intentionally left blank.]

## Dear Funtastic Customer,

Thank YOU for choosing one of our Funsicle products. We're on a mission to inspire the world to play more outdoors, which is why we design products that capture the summertime spirit of imagination, connection and fun.

It's important to us that you have the BEST experience with this product, and we're excited for you to make some happy outdoor memories.


Need a helping hand? Use the contact info on this page to reach us.

Once again, we thank you for placing your trust in us. Happy swimming and playing!

- Your friends, the Funsicle Team

## CONTACT US

We're here to help! For answers to common questions, setup videos and troubleshooting tips, visit [funsicle.com/support](https://funsicle.com/support) or scan the QR code.



### DO NOT RETURN PRODUCT TO STORE.

If you encounter any issues with your Funsicle product, do not return it to the place of purchase.


Contact CUSTOMER SERVICE:

**Phone: 888-670-4FUN (888-670-4386)**

**Email: [HelloFun@Funsicle.com](mailto:HelloFun@Funsicle.com)**

### REGISTER YOUR PRODUCT

Scan the QR code



# Funsicle®

#### Distributed by:

Polygroup Pacific Limited  
Unit 606, 6th Floor, Fairmont House,  
8 Cotton Tree Drive, Central, Hong Kong.