


FunSicle®

Serenity Blue Pool



User Guide



Sign up for future
offers and discounts.
Scan the QR Code.

Welcome!

Congratulations on your new Funsicle Serenity Blue Pool. This guide will walk you through everything from setting up to maintaining and enjoying your pool.

As always, we're here to help. For any issues, questions, or extra support, visit funsicle.com/support, or contact Customer Service at 888-670-4FUN (888-670-4386) or HelloFun@Funsicle.com.

Safety Guidelines

IMPORTANT SAFETY INSTRUCTIONS

When installing and using this product, basic safety precautions should always be followed, including the following:


READ AND FOLLOW ALL INSTRUCTIONS

Keep this User Guide for future reference. Failure to follow these warnings and instructions can result in serious injury or death to users, especially children.

Warnings

⚠ WARNING

PREVENT DROWNING!



- Closely watch children who are in or near this pool.
- Children under 5 are at highest risk for drowning.
- Do not leave child unattended while in use.
- Use only under competent supervision.
- Empty the pool or prevent access when not in use.



NO DIVING!

You can break your neck and be paralyzed.

Empty the pool when not in use to prevent children from gaining unauthorized access and drowning.

Read and follow all safety information and assembly instructions in the User Guide.

SAFETY CARE FOR CHILDREN

- Prevent Young Children from Drowning:
 - a. Install fencing or approved barrier around all sides of pool.
 - b. Children under 5 years old are at highest risk for drowning.
 - c. Closely watch children who are in or near this pool.
 - d. Empty pool or prevent access when not in use.
- Prevent Young Children from Gaining Access to Pool:
 - a. Remove pool ladders before leaving the pool. Toddlers can climb the ladder and get into the pool.
 - b. Position furniture away from the pool so that children cannot climb and gain access to the pool.
 - c. When leaving the pool, remove floats and toys from the pool that might attract a child.
- Assign an adult to be responsible for watching children in the pool. Give this person a "water watcher" tag and ask that they wear it the entire time they are in charge of supervising children in

the pool. If they need to leave for any reason, ask this person to pass the “water watcher” tag and the supervision responsibility to another adult. **For replacement of the water watcher tag, visit [funsicle.com](https://www.funsicle.com)**

- Pool presents a drowning hazard even during filling and draining of the pool. Maintain constant supervision of children and do not remove any safety barriers until the pool is completely empty and stowed away.
- Drowning occurs silently and quickly and can occur in as little as 2 inches (5 cm) of water.
- Keep children in your direct sight, stay close, and actively supervise them when they are in or near this pool and when you are filling and emptying this pool.
- When searching for a missing child, check the pool first, even if the child is thought to be in the house.
- Empty pool completely after each use, and store the empty pool in such a way that it does not collect water from rain or any other source.
- Keep unsupervised children from accessing the pool by installing fencing or other approved barriers around all sides of the pool. State or local laws or codes may require fencing or other approved barriers. Check state or local laws and codes before setting up pool.
- See latest published edition of CPSC Pub. No. 362 found at [poolsafely.gov](https://www.poolsafely.gov).
- Do not leave toys inside pool when finished using the pool, since toys and similar items might attract a child to the pool. Position furniture (e.g. tables, chairs) away from pool, so that children cannot climb on it to gain access to the pool. After using pool, remove water to a level of 1/2 inches (1 cm) or less.

DIVING RISK

Do not dive into this pool. Diving into shallow water can result in a broken neck, paralysis, or death.

ELECTROCUTION RISK

Keep all electrical lines, radios, speakers, and other electrical appliances away from the pool. Do not place pool near or under overhead electrical lines.

FIRST AID

Keep a working phone and a list of emergency numbers near the pool. Become certified in cardiopulmonary resuscitation (CPR). In the event of an emergency, immediate use of CPR can make a life-saving difference.

WARNING

- This pool must be assembled on a smooth and level site of firm soil that is free of stones, gravel, sticks, black-top or other oil based compounds.
- Do not install pool on a wooden deck or any type of wooden surface.
- Do not install the pool on a slope or inclined surfaces, on soft or loose soil conditions (e.g. sand or mud), or on an elevated surface such as a deck, platform or balcony, which may collapse under the weight of the filled pool.
- This pool should be set up so that it complies with local safety and building codes. The pool is to be assembled by an adult. Care should be taken in the unpacking and assembly of the pool. This pool may contain accessible potentially hazardous sharp edges or sharp points that are a necessary part of the function of the pool.
- **CAUTION:** Keep out of baby's reach.
- **WARNING:** Use only under supervision.
- The product must be assembled and disassembled by adult.
- **WARNING:** For domestic use only.

Consumer Awareness Booklets

Contact U.S. Consumer Product Safety Commission (CPSC) at poolsafely.gov for publication "Safety Barrier Guidelines for Residential Pools". Contact The Association of Pool & Spa Professionals (APSP, formerly NSPI) at www.APSP.org for these publications: "The Sensible Way to Enjoy Your Above-ground/On-ground Swimming Pool", "Children Aren't Waterproof", "Pool and Spa Emergency Procedures for Infants" and "Layers of Protection".

Danger: Competent supervision and knowledge of the safety requirements is the only way to prevent drowning or permanent injury in the use of this product. Never leave young children unattended.

SAVE THESE INSTRUCTIONS

Setting Up Your Pool

1. Locate a clean area free of stones or other sharp objects to inflate the pool.
2. Inflate the air chambers following the numbered sequence (if any) slowly with a manual/foot air pump.
Use adequate air pressure: Make sure the pool is firm to the touch but NOT hard – there should be small folds around the armrests, backrests and/or side edges, and below the cup holders (if any). Also compare the pressure with that of the large main chamber.
3. Close and press the inflation valves into the unit to get a flat surface.
4. Fill the pool to the FILL LINE marked on its inner wall or slightly below the top edge of the pool. Do not overfill the pool.


CAUTIONS:

- Inflate by adult only.
- DO NOT overinflate.
- To prevent bursting, do not inflate with high pressure pump such as an air compressor, or exceed the recommended Design Working Pressure.
- Inflate with cold air only.
- Check regularly to ensure the adequate air pressure during each use, especially on very hot or cold days.

Using the 2-in-1 Valve


If your pool includes a 2-in-1 valve, use the following steps to quickly inflate and deflate your pool.

To inflate:



1. Press the Inflation Valve into the Exhaust Port.
2. Ensure the Inflation Valve snaps firmly into place.
3. Remove the Top Cap.
4. Inflate with an air pump.
5. Close the Top Cap tightly to seal the valve after inflation.
6. To lock, press the valve all the way in.

To deflate:




1. Pull out the Top Cap until both the Top Cap and Inflation Valve are completely open.
2. To quickly push out all the air, fold up the pool.

Using the AirFlate Tool


If your pool comes with an AirFlate Tool (packed in a transparent Ziplock bag inside your product box), use the following steps to quickly inflate and deflate your pool.

NOTE: This tool can only be used on regular air valves. It cannot be used on a 2-in-1 valve or a Boston valve as the sizes do not match.


To inflate:



1. Insert the AirFlate Tool into the air valve.




2. Twist it to open the valve.




3. Blow air into the valve.


To deflate:



1. Insert the AirFlate Tool into the air valve.



2. Twist it to open the valve.



3. Let the air release completely.

CAUTIONS:

- This tool is not a toy.
- Keep this tool out of reach of children and avoid misuse to prevent potential danger of choking or poking an eye.

Emptying and Deflating Pool

Deflate pool and/or push down on the side wall to empty pool water and/or lift up one side of pool to empty pool water.

NOTES:

- Pool should be cleaned with mild soap and lukewarm water only.
- Make sure pool is completely dry before storing to help prevent mildew from forming.
- Store all parts in a dry, temperature-controlled area where temperatures do not go below 32°F or above 125°F.
- Use a small patch kit to repair punctures or holes in pool.

Repairing Your Pool

1. Use a mix of liquid dish soap and water in a spray bottle, and spray over suspicious areas. Any leak will produce bubbles that will pinpoint the location of the leak.
2. Thoroughly clean the area surrounding the leak to remove any dirt or grime.
3. Cut a piece of repair patch (included) with a margin of 0.8 inches (2 cm) larger than the damaged area, rounding the corners with scissors.
4. Place the patch over the center of the leak, press down firmly, and squeeze out all air bubbles to the edges. You may want to put a weight on top to keep it in place.
5. Do not inflate for one hour after patching.

NOTE:

If the patch does not hold, you can use the patch with silicone or polyurethane-based glue designed for repairing camping mats, tents or shoes. Consult your local household/camping supply stores, and follow the instructions of the glue you have chosen.

Dear Funtastic Customer,

Thank YOU for choosing one of our Funsicle products. We're on a mission to inspire the world to play more outdoors, which is why we design products that capture the summertime spirit of imagination, connection and fun.

It's important to us that you have the BEST experience with this product, and we're excited for you to make some happy outdoor memories.


Need a helping hand? Use the contact info on this page to reach us.

Once again, we thank you for placing your trust in us. Happy swimming and playing!

- Your friends, the Funsicle Team

CONTACT US

We're here to help! For answers to common questions, setup videos and troubleshooting tips, visit funsicle.com/support or scan the QR code.



DO NOT RETURN PRODUCT TO STORE.

If you encounter any issues with your Funsicle product, do not return it to the place of purchase.


Contact CUSTOMER SERVICE:

Phone: 888-670-4FUN (888-670-4386)

Email: HelloFun@Funsicle.com

REGISTER YOUR PRODUCT

Scan the QR code



Funsicle®

Distributed by:

Polygroup Pacific Limited
Unit 606, 6th Floor, Fairmont House,
No.8 Cotton Tree Drive, Central, Hong Kong.