

nureva®

HDL300 and DUAL HDL300

QUICK START GUIDE

PACKAGE CONTENTS

A B C D E F G H I

Diagram showing the components included in the package: A (HDL300 unit), B (HDL300 unit), C (HDL300 unit), D (HDL300 unit), E (HDL300 unit), F (HDL300 unit), G (HDL300 unit), H (HDL300 unit), I (HDL300 unit).

Diagram showing the installation steps for the HDL300 unit, including mounting bracket placement and unit attachment.

Diagram showing the recommended mounting height and distance for the HDL300 unit.

Diagram showing the recommended mounting height and distance for the HDL300 unit.

Diagram showing the dimensions of the HDL300 unit: 60" (152.4 cm) width, 5 7/8" (14.9 cm) height, and 31 1/2" (80.0 cm) depth.

YOU WILL NEED

Diagram showing the tools and materials required for installation: a ladder, a measuring tape, a pencil, a power drill, #10 pan head anchors or M5 pan head anchors, a screwdriver, #10 pan head screws or M5 pan head screws, and a laptop with the Nureva website.

Download the installation guide: links.nureva.com/downloadconsoleclient

DUAL HDL300

Diagram showing the recommended mounting height and distance for the DUAL HDL300 unit.

Diagram showing the recommended mounting height and distance for the DUAL HDL300 unit.

Diagram showing the recommended mounting height and distance for the DUAL HDL300 unit.

REMOTE CONTROL

Diagram showing the remote control layout and the functions of the buttons.

Buttons: Answer Call, Mute, Volume, LED Brightness, End Call, F1, F2, F3, F4.

Functions: Answer Call, Mute, Volume, LED Brightness, End Call, F1, F2, F3, F4.

