

Nureva Audio Evaluation Kit

Safety and handling information



WARNING: FAILURE TO FOLLOW THESE DIRECTIONS AND WARNINGS COULD RESULT IN SERIOUS INJURY OR DEATH.

The stand (with the included backboard) is intended to be used to mount the Nureva HDL300, HDL310 and HDL410 systems only. Do not use the stand with any other equipment or for any other purpose.

Directions

- The stand is heavy. Two individuals are required to unpack, assemble, and move the stand. Use proper technique when assembling, lifting and moving the stand to prevent back or crush injuries or dropping the stand.
- Assemble the stand on a stable level surface at ground level and not on an elevated platform or shelf.
- Ensure that the legs of the stand are fully extended and secured before raising the pole section of the stand.
- The stand should be placed out of traffic paths to reduce the risk that it may be bumped into and tipped over.
- Keep children away from the stand. Climbing, hanging or rocking the stand could cause it to tip and result in serious injury or death.
- Be especially careful when moving the stand to insure it does not tip over.

To clean the stand, wipe it gently with a clean cloth and a neutral cleaning solution. Do not use harsh chemicals, like alcohol, acetone, bleach, paint thinner, benzene, other petrochemicals to clean the stand.