

# CHROMASENS

Offline User Manual for allPIXA neo Version  
1.0.0



# Table of Contents

## Line Scan Cameras > Safety

Safety .....	6
Safety instructions .....	6
Meaning of the signal words, safety signs and graphical symbols .....	6
Signal words .....	6
Safety signs and graphical symbols .....	6
Personnel requirements .....	7
Untrained person .....	7
Qualified personnel .....	7
Assignment of the tasks .....	7

## Line Scan Cameras > allPIXA neo series > Introduction

About this instruction manual .....	8
History .....	8
Version 1.0.0 .....	8
Overview .....	9
Firmware and software version .....	9
Feature reference .....	9
Software GCT .....	9
Intended use .....	10
Line scan system .....	11

## Line Scan Cameras > allPIXA neo series > Models

Overview .....	12
Available cameras .....	12
allPIXA neo 4k GigE .....	13
Camera specifications .....	13
Line scan sensor .....	13
Sensor pixel arrangement .....	13
Spectral sensitivity .....	14
Sensor alignment and orientation .....	14
Mechanical dimensions .....	15
Interface specification .....	15
Line rate .....	16
Power supply .....	16
Digital I/O port .....	16
LED status indicator .....	18
allPIXA neo 4k CXP .....	19
Camera specifications .....	19
Line scan sensor .....	19
Sensor pixel arrangement .....	19
Spectral sensitivity .....	20
Sensor alignment and orientation .....	20
Mechanical dimensions .....	21
Interface specification .....	21
Line rate .....	22
Power supply .....	22
Digital I/O port .....	22
LED status indicator .....	24

allPIXA neo 6k GigE .....	26
Camera specifications .....	26
Line scan sensor .....	26
Sensor pixel arrangement .....	26
Spectral sensitivity .....	27
Sensor alignment and orientation .....	28
Mechanical dimensions .....	29
Interface specification .....	29
Line rate .....	30
Power supply .....	30
Digital I/O port .....	30
LED status indicator .....	32
allPIXA neo 6k CXP .....	33
Camera specifications .....	33
Line scan sensor .....	33
Sensor pixel arrangement .....	33
Spectral sensitivity .....	34
Sensor alignment and orientation .....	35
Mechanical dimensions .....	36
Interface specification .....	36
Line rate .....	37
Power supply .....	37
Digital I/O port .....	37
LED status indicator .....	39

## Line Scan Cameras > allPIXA neo series > Installation

Unboxing .....	41
Mechanical installation .....	42
Prepare the camera and lens .....	42
Thermal link and cooling .....	42
Adjust and install your illumination .....	42
Install the camera in your system .....	42
Mounting .....	43
Conveyor belt tracking .....	43
Perpendicularity of the sensor to the direction of transport .....	44
Rotation around the longitudinal axis of the sensor .....	44
Rotation around the transverse axis of the sensor .....	45
Electrical installation .....	46
GigE interface .....	46
Network adapter .....	46
Cabling .....	46
CXP interface .....	46
Frame grabber .....	47
Cabling .....	47
Digital I/O port .....	47
Configure the I/O's .....	49
Circuit Diagrams .....	49
Software installation and configuration .....	51
Starter-Kit .....	52
Unboxing .....	52
Getting Started .....	52
Further Steps .....	52

## Line Scan Cameras > allPIXA neo series > Getting started > First images

Acquire the first image .....	54
Connect the camera .....	54
Load the default user set .....	54
Acquire an image .....	55
Video description .....	55
Acquire a test pattern .....	56
Load the default user set .....	56
Generate a test pattern .....	56
Compare the template to the generated image .....	56
Video description .....	57
Acquire images with frame and line trigger .....	58
Setup the frame trigger .....	58
Setup the line trigger .....	58

## Line Scan Cameras > allPIXA neo series > Getting started > Camera image calibration

Introduction .....	60
Perform white balancing .....	61
Prepare your system .....	61
Configure the gain settings .....	61
Adjust the lens .....	65
Create a black-reference (DSNU) .....	67
Create a shading-reference (PRNU) .....	69
Standard PRNU reference generating .....	69
Extrapolation function .....	70
Safe the setting .....	72
Check the image quality .....	73

## Line Scan Cameras > allPIXA neo series > Camera operation - how to

Set a frame trigger .....	74
Internal frame trigger .....	74
External frame trigger .....	74
Signal type .....	74
Input signal activation .....	76
Trigger signal detection mode .....	79
Set a line trigger .....	83
Internal line trigger .....	83
External line trigger .....	83
Signal type: Single-ended (LVCMOS) .....	83
Signal type: Differential (RS422) .....	84
Configurations of the external line trigger .....	86
Create a black-reference (DSNU) .....	87
Create a shading-reference (PRNU) .....	89
Standard PRNU reference generating .....	89
Extrapolation function .....	90
Updating the firmware .....	92

## Line Scan Cameras > allPIXA neo series > Feature reference - guide

Overview .....	94
Release 1.0.0 - (November 2023) .....	94



Camera Firmware 1.0.0 .....	95
Feature Reference .....	95
Release Notes .....	95

## **Line Scan Cameras > allPIXA neo series > Troubleshooting**

Troubleshooting .....	96
-----------------------	----

## **Line Scan Cameras > allPIXA neo series > Maintenance and disposal**

Maintenance and disposal .....	97
Safety instructions .....	97
Cleaning .....	97
Cleaning intervals .....	97
Cleaning procedure .....	97
Repair .....	97
Disposal .....	97

# Safety

## Safety instructions

- Operate the device only in a faultless and safe condition.
- Modifications and extensions to the device are only permitted if the prior written consent of [Chromasens GmbH](#) is obtained.
- Comply with the ambient conditions described in this manual.
- During operation do not touch the hot surface of the device.
- During operation do not use detergents on the device.

## Meaning of the signal words, safety signs and graphical symbols



### Signal words


The following signal words are used in this manual:

Signal word	Meaning, consequences if not prevented
DANGER	Warns of an imminent hazardous situation which results in death or serious injury.
WARNING	Warns of a potential hazardous situation, which could result in death or serious injury.
CAUTION	Warns of a potential hazardous situation, which could result in minor or moderate injury.
NOTICE	Warns of a hazardous situation, which can result in material damage or environmental damage.

### Safety signs and graphical symbols

The following safety signs and graphical symbols are used:

Sign	Meaning
	Warning of dangerous electrical voltage
	Warning of falling items

	Warning of hot surface
	Warning of potential damage to the device
	Indicates that electrical and electronic equipment should not be disposed with normal garbage at the end of its working life.

## Personnel requirements

### Untrained person

The untrained person has been instructed by the operating company or an authorised representative of the operating company (qualified personnel) about the tasks assigned to him and the possible dangers in case of improper behaviour. The untrained person has been instructed about the protective measures and the operating tasks. The untrained person has sufficient knowledge of the national language, both written and spoken.

### Qualified personnel

Qualified personnel are persons who, due to their professional training, knowledge and experience as well as knowledge of the relevant standards and regulations, carry out the work assigned to them, assess it and independently recognize possible dangers independently. The person knows the operating instructions of the machine. Skilled personnel are mechanics, electricians and technicians.

### Assignment of the tasks

Task	Untrained person	Qualified personnel
Installation	Prohibited	Allowed
Programming	Prohibited	Allowed
Calibration	Prohibited	Allowed
Testing	Prohibited	Allowed
Cleaning	Allowed	Allowed
Repairing	Prohibited	Prohibited

## About this instruction manual

This instruction manual provides the necessary information for safe and efficient use of the product throughout its life cycle.

### Representational tools

- Font markup **bold**: clickable areas in the software GCT.
- Font markup *italic*: windows and views to navigate to in the software GCT.

The instructions and descriptions for using the camera are based on the inhouse software GCT.

## History

### Version 1.0.0

Initial version of this Documentation, November 2023.

### Offline version


#### [Download as pdf-file](#)

[Download the latest version of the online documentation.](#)

## Overview

The cameras offer CMOS performance with CCD image quality. There are line rates possible of up to 300 kHz.

The cameras fulfill the GenICam standard communication protocol. You can set up the camera, browse and adjust parameters with every tool that fulfills the GenICam standard. The provided Chromasens GCT software is available for Windows and Linux.



Scheme of the communication between a host software and the camera

## Firmware and software version

This documentation refers to the following version:

Camera: Packet 1.0.0

## Feature reference

For detailed information on camera controls refer to the [feature reference](#). It describes the standard and advanced camera control.

Make sure that you always refer to the feature reference that matches the used firmware version.

## Software GCT


Refer to the [GCT documentation](#) for the following information:

- Installation and use
- Configuration of the PC depending on the camera interface

## Intended use

- The device is designed for machines and systems which are used for commercial and industrial applications.
- The device is designed for contactless optical detection of primarily two dimensional objects.
- The device may only be connected or used as described in this manual.
- Do not use the device in safety relevant control circuits and potentially explosive environment.

# Line scan system



<p><b>1</b> Line scan camera: Scans the image line by line and communicates with the PC.</p>	<p><b>2</b> Optical system: Lenses and mounts</p>
<p><b>3</b> Illumination: Lights up the information carrier/scan area.</p>	<p><b>4</b> Illumination controller: Controls and monitors the illumination unit.</p>
<p><b>5</b> Cables and suitable network card or frame grabber in the PC: The image data are sent to a PC.</p>	<p><b>6</b> PC: The PC performs subsequent processing of the image data and can optionally control the illumination system.</p>
<p><b>7</b> Speed detection: The speed of the object/conveyor belt can be detected by an optional incremental encoder. The encoder can be connected to the camera.</p>	<p><b>8</b> Conveying unit: Moves the scanned object.</p>
<p><b>9</b> Frame trigger: A light barrier can be used to detect the object and start the image acquisition on time. The frame trigger can be connected to the camera.</p>	

## Overview

The allPIXA neo line scan cameras are available with the GigE interface and the CXP interface. The available sensor resolutions are 4k and 6k. The cameras support color and mono.

The rating plate is located on the rear of the camera. It shows the sensor resolution and the serial number.

### Available cameras

Camera	Order number	Interface	Sensor type
allPIXA neo 4k 10GigE Mono	CP000660-04K-77-M1-A1	GigE	Mono
allPIXA neo 4k 10GigE Color	CP000660-04K-77-C1-A1	GigE	Color + Mono
allPIXA neo 6k 10GigE Mono	CP000660-06K-77-M1-A1	GigE	Mono
allPIXA neo 6k 10GigE Color	CP000660-06K-77-C1-A1	GigE	Color + Mono
allPIXA neo 6k 10GigE Color-NIR	CP000660-06K-77-C2-A1	GigE	Color + NIR
allPIXA neo 4k CXP Mono (on request)	CP000660-04K-44-M1-A1	CXP	Mono
allPIXA neo 4k CXP Color	CP000660-04K-44-C1-A1	CXP	Color + Mono
allPIXA neo 6k CXP Mono (on request)	CP000660-06K-44-M1-A1	CXP	Mono
allPIXA neo 6k CXP Color	CP000660-06K-44-C1-A1	CXP	Color + Mono
allPIXA neo 6k CXP Color-NIR	CP000660-06K-44-C2-A1	CXP	Color + NIR




# allPIXA neo 4k GigE

## Camera specifications

Sensor	CMOS
Pixel size	7 $\mu\text{m}$ $\times$ 7 $\mu\text{m}$
Line spacing	7 $\mu\text{m}$ between M-G & G-B & B-R
Spectral sensitivity	400 nm – 960 nm
Resolution	4096 $\times$ 4 lines
Video output	Single 10 GigE, GigE Vision® 2.0 compliant
Data format	3 $\times$ 8/10/12 Bit color or 1 $\times$ 8/10/12 Bit mono or 4 $\times$ 8/10/12 RGB + Mono
Trigger Mode	Frame Start / Frame Active / Frame Burst Start / Line Start / External Encoder
Video output port	RJ45 (10GBase-T)
Digital I/O port	External I/O (15 pin HD D-Sub, male)
Power supply	PoE (Power over Ethernet) or digital I/O port: 12 – 24V DC $\pm$ 10 %
Debugging port	-
Lens mount / adapter	M42 $\times$ 1 mm / F-Mount, TFL
Housing dimensions	62 mm $\times$ 62 mm $\times$ 62 mm
Weight	0,35 kg
Temperature during operation	0 $^{\circ}\text{C}$ – 60 $^{\circ}\text{C}$ ; 32 $^{\circ}\text{F}$ – 140 $^{\circ}\text{F}$
Humidity during operation	20 % – 85 % relative air humidity, non condensing
Temperature during transport and storage	-20 $^{\circ}\text{C}$ – +85 $^{\circ}\text{C}$ ; -4 $^{\circ}\text{F}$ – +185 $^{\circ}\text{F}$
Protection category	IP50
Certifications	CE, RoHS
General ambient conditions	
Transport	IEC 721-3-3:IE33
Operation	IEC 721-3-3:IE21
Storage	IEC 721-3-3:IE11


## Line scan sensor

## Sensor pixel arrangement




Sensor line spacing and pixel arrangement of the 4k sensor

## Spectral sensitivity




Measured relative sensitivity of the color and the mono sensor

## Sensor alignment and orientation



Alignment and orientation of the 4k sensor: Color + Mono

## Mechanical dimensions




Dimensional drawing of the allPIXA neo 4k/6k 10GigE

[Download as pdf-file](#)

[Download dimensional drawing of the allPIXA neo 4k/6k 10GigE](#)

## Interface specification



<b>1</b>	Video output port 10GigE (RJ45) and power supply	<b>2</b>	Digital I/O port and power supply
<b>3</b>	Status LED	<b>4</b>	Connector for additional fan

**Line rate**

Configuration (8 bit)	Line rate
Mono	270 kHz
RGB	90 kHz
RGB + Mono (NIR)	70 kHz


**Power supply**

You can either use Power over Ethernet (PoE) or the power supply of the external digital I/O port.

**Digital I/O port**

The following connector is required for the digital I/O port:

- 15 pin HD D-Sub (female)



Pin allocation D-Sub connector (male) of the camera

You can configure the digital I/O port as RS422 or as single-ended input or output. It is also possible to configure one output as RS422 and the other output as single-ended.

## RS422 configuration

Pin	Line definition for RS422 configuration	Signal RS422	Configuration proposal
1	Line 1	In1+	Encoder Source A, Line Start
2		In1-	Encoder Source A\, Line Start\
3	Line 2	In2+	Encoder Source B, Fame Start, Frame Active
4		In2-	Encoder Source B\, Fame Start\, Frame Active\
5	GND (Signals)		Signals Ground
6	Line 3	In3+/Out3+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7		In3-/Out3-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output3-
8	Line 4	In4+/Out4+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+, MS-In+
9		In4-/Out4-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output4-, MS-In-
10	GND (PWR)		Camera Power Ground
11	Line 5	Out5+	User Output5+, MS-Out+
12		Out5-	User Output5-, MS-Out-
13	Line 6	Out6+	User Output6+
14		Out6-	User Output6-
15	Vcc (PWR)		Camera Power DC +12 V – +24 V








## Single-Ended (SE) configuration

The input threshold voltage can be configured globally to 3.3 V, 5 V, 12 V and 24 V. The Maximum input voltage is 28 V.

Pin	Line definition for Single-Ended configuration	Signal Single-Ended	Configuration proposal
1	Line 1	In1 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source A, Line Start
2	--	--	--
3	Line 2	In2 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source B, Fame Start, Frame Active
4	--	--	--
5	GND (Signals)		Signals Ground
6	Line 3	In3 (3.3 V, 5 V, 12 V, 24 V) Out3 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7	--	--	--
8	Line 4	In4 (3.3 V, 5 V, 12 V, 24 V) Out4 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+
9	--	--	--
10	GND (PWR)		Camera Power Ground

11	Line 5	In5 (3.3 V) Out5 (3.3 V)	LED Flash Out 3, User Output5
12	Line 7	In7 (3.3 V) Out7 (3.3 V)	LED Flash Out 2, User Output7
13	Line 6	In6 (3.3 V) Out6 (3.3 V)	LED Flash Out 0, User Output6
14	Line 8	In8 (3.3 V) Out8 (3.3 V)	LED Flash Out 1, User Output8
15	Vcc (PWR)		Camera Power DC +12 V – +24 V

## LED status indicator

Color code	Behaviour	Description
	Off	No power supply or the <a href="#">input voltage</a> is out of range.
	Blue continuous	The device is OK and provides image data.
	Green continuous	The device is in power-up mode.
	Green blinking	The device is OK and ready.
	Green/Blue alternative	The device is OK and provides image data frequently, based on a trigger signal.
	Yellow continuous	<a href="#">Warning-state</a> : The device is operational.
	Red continuous	<a href="#">Error-state</a> : The device is not operational.


# allPIXA neo 4k CXP

## Camera specifications

Sensor	CMOS
Pixel size	7 $\mu\text{m}$ $\times$ 7 $\mu\text{m}$
Line spacing	7 $\mu\text{m}$ between M-G & G-B & B-R
Spectral sensitivity	400 nm – 960 nm
Resolution	4096 $\times$ 4 lines
Video output	2 $\times$ CoaXPress 2.0
Data format	3 $\times$ 8/10/12 Bit color or 1 $\times$ 8/10/12 Bit mono or 4 $\times$ 8/10/12 RGB + Mono
Trigger Mode	Frame Start / Frame Active / Frame Burst Start / Line Start / External Encoder
Video output port	2 $\times$ CXP-12 Micro-BNC
Digital I/O port	External I/O (15 pin HD D-Sub, male)
Power supply	PoC (Power over CoaXPress) or digital I/O port: 12 – 24V DC $\pm$ 10 %
Debugging port	-
Lens mount / adapter	M42 $\times$ 1 mm / F-Mount, TFL
Housing dimensions	62 mm $\times$ 62 mm $\times$ 62 mm
Weight	0,35 kg
Temperature during operation	0 $^{\circ}\text{C}$ – 60 $^{\circ}\text{C}$ ; 32 $^{\circ}\text{F}$ – 140 $^{\circ}\text{F}$
Humidity during operation	20 % – 85 % relative air humidity, non condensing
Temperature during transport and storage	-20 $^{\circ}\text{C}$ – +85 $^{\circ}\text{C}$ ; -4 $^{\circ}\text{F}$ – +185 $^{\circ}\text{F}$
Protection category	IP50
Certifications	CE, RoHS
General ambient conditions	
Transport	IEC 721-3-3:IE33
Operation	IEC 721-3-3:IE21
Storage	IEC 721-3-3:IE11


## Line scan sensor

## Sensor pixel arrangement



Sensor line spacing and pixel arrangement of the 4k sensor


## Spectral sensitivity



Measured relative sensitivity of the color and the mono sensor


## Sensor alignment and orientation





Alignment and orientation of the 4k sensor: Color + Mono

## Mechanical dimensions




Dimensional drawing of the allPIXa neo 4k/6k CXP

[Download as pdf-file](#)

[Download dimensional drawing of the allPIXa neo 4k/6k CXP](#)

## Interface specification



### Line rate

Configuration (8 bit)	Line rate
Mono	300 kHz
RGB	105 kHz
RGB + Mono (NIR)	80 kHz


### Power supply

You can either use Power over CoaXPress (PoC) or the power supply of the external digital I/O port.

### Digital I/O port

The following connector is required for the digital I/O port:

- 15 pin HD D-Sub (female)



You can configure the digital I/O port as RS422 or as single-ended input or output. It is also possible to configure one output as RS422 and the other output as single-ended.

## RS422 configuration

Pin	Line definition for RS422 configuration	Signal RS422	Configuration proposal
1	Line 1	In1+	Encoder Source A, Line Start
2		In1-	Encoder Source A\, Line Start\
3	Line 2	In2+	Encoder Source B, Fame Start, Frame Active
4		In2-	Encoder Source B\, Fame Start\, Frame Active\
5	GND (Signals)		Signals Ground
6	Line 3	In3+/Out3+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7		In3-/Out3-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output3-
8	Line 4	In4+/Out4+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+, MS-In+
9		In4-/Out4-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output4-, MS-In-
10	GND (PWR)		Camera Power Ground
11	Line 5	Out5+	User Output5+, MS-Out+
12		Out5-	User Output5-, MS-Out-
13	Line 6	Out6+	User Output6+
14		Out6-	User Output6-
15	Vcc (PWR)		Camera Power DC +12 V – +24 V

## Single-Ended (SE) configuration






The input threshold voltage can be configured globally to 3.3 V, 5 V, 12 V and 24 V. The Maximum input voltage is 28 V.

Pin	Line definition for Single-Ended configuration	Signal Single-Ended	Configuration proposal
1	Line 1	In1 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source A, Line Start
2	--	--	--
3	Line 2	In2 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source B, Fame Start, Frame Active
4	--	--	--
5	GND (Signals)		Signals Ground
6	Line 3	In3 (3.3 V, 5 V, 12 V, 24 V) Out3 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7	--	--	--
8	Line 4	In4 (3.3 V, 5 V, 12 V, 24 V) Out4 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+
9	--	--	--
10	GND (PWR)		Camera Power Ground

11	Line 5	In5 (3.3 V) Out5 (3.3 V)	LED Flash Out 3, User Output5
12	Line 7	In7 (3.3 V) Out7 (3.3 V)	LED Flash Out 2, User Output7
13	Line 6	In6 (3.3 V) Out6 (3.3 V)	LED Flash Out 0, User Output6
14	Line 8	In8 (3.3 V) Out8 (3.3 V)	LED Flash Out 1, User Output8
15	Vcc (PWR)		Camera Power DC +12 V – +24 V

## LED status indicator

Color code	Behaviour	Description
	Off	No power supply or the <a href="#">input voltage</a> is out of range.
	Solid orange	The system is booting.
	Flash_1_1red	The device is powered but not connected (not applicable to a device reliant on PoCXP power).
	AlternateFlash_12_5 green/orange; shown for a minimum of 1s even if connection detection is faster	The Connection detection is in progress, PoCXP is active.
	Flash_12_5 orange; shown for a minimum of 1s even if connection detection is faster	The Connection detection is in progress, PoCXP is not in use.
	AlternateFlash_0_5 red/green	The device/host is incompatible, PoCXP is active.
	AlternateFlash_0_5 red/orange	The device/host is incompatible, PoCXP is not in use.
	Solid red	PoCXP is over-current (host only).
	Solid green	The device/host is connected, but no data is transferred.
	Flash_1_ orange	The device/host is connected, waiting for event (e.g. trigger).

	Flash_12_5 green	The device/host is connected, data is being transferred.
	500ms red pulse	Error during data transfer (e.g. CRC error, single-bit error) is detected. In case of multiple errors, there shall be at least two green Flash_12_5 pulses, before the next error is indicated.
	AlternateFlash_0_5 green/orange	A connection test packet is being sent.
	AlternateFlash_0_5 red/green/orange	The compliance test mode is enabled (device only).
	Flash_12_5 red	A system error (e.g. internal error) occurred.


# allPIXA neo 6k GigE

## Camera specifications

Sensor	CMOS
Pixel size	5 $\mu\text{m}$ $\times$ 5 $\mu\text{m}$
Line spacing	5 $\mu\text{m}$ between R-G & G-B & B-M, for NIR 195 $\mu\text{m}$ between NIR-R
Spectral sensitivity	400 nm – 960 nm
Resolution	6144 $\times$ 4 lines
Video output	Single 10 GigE, GigE Vision® 2.0 compliant
Data format	3 $\times$ 8/10/12 Bit color or 1 $\times$ 8/10/12 Bit mono or 4 $\times$ 8/10/12 RGB + Mono
Trigger Mode	Frame Start / Frame Active / Frame Burst Start / Line Start / External Encoder
Video output port	RJ45 (10GBase-T)
Digital I/O port	External I/O (15 pin HD D-Sub, male)
Power supply	PoE (Power over Ethernet) or digital I/O port: 12 – 24V DC $\pm$ 10 %
Debugging port	-
Lens mount / adapter	M42 $\times$ 1 mm / F-Mount, TFL
Housing dimensions	62 mm $\times$ 62 mm $\times$ 62 mm
Weight	0,35 kg
Temperature during operation	0 $^{\circ}\text{C}$ – 60 $^{\circ}\text{C}$ ; 32 $^{\circ}\text{F}$ – 140 $^{\circ}\text{F}$
Humidity during operation	20 % – 85 % relative air humidity, non condensing
Temperature during transport and storage	-20 $^{\circ}\text{C}$ – +85 $^{\circ}\text{C}$ ; -4 $^{\circ}\text{F}$ – +185 $^{\circ}\text{F}$
Protection category	IP50
Certifications	CE, RoHS
General ambient conditions	
Transport	IEC 721-3-3:IE33
Operation	IEC 721-3-3:IE21
Storage	IEC 721-3-3:IE11


## Line scan sensor

## Sensor pixel arrangement




Left: Sensor line spacing and pixel arrangement of the 6k sensor  
 Right: Sensor line spacing and pixel arrangement of the 6k sensor with NIR

## Spectral sensitivity




Measured relative sensitivity of the color and the mono sensor




Measured relative spectral sensitivity of the 6k sensor with NIR

### Sensor alignment and orientation




Alignment and orientation of the 6k sensor: Color + Mono





Alignment and orientation of the 6k sensor: Color + NIR

## Mechanical dimensions




Dimensional drawing of the allPIXA neo 4k/6k 10GigE

[Download as pdf-file](#)

[Download dimensional drawing of the allPIXA neo 4k/6k 10GigE](#)

## Interface specification



### Line rate

Configuration (8 bit)	Line rate
Mono	180 kHz
RGB	58 kHz
RGB + Mono (NIR)	45 kHz


### Power supply

You can either use Power over Ethernet (PoE) or the power supply of the external digital I/O port.

### Digital I/O port

The following connector is required for the digital I/O port:

- 15 pin HD D-Sub (female)



Pin allocation D-Sub connector (male) of the camera

You can configure the digital I/O port as RS422 or as single-ended input or output. It is also possible to configure one output as RS422 and the other output as single-ended.

## RS422 configuration

Pin	Line definition for RS422 configuration	Signal RS422	Configuration proposal
1	Line 1	In1+	Encoder Source A, Line Start
2		In1-	Encoder Source A\, Line Start\
3	Line 2	In2+	Encoder Source B, Fame Start, Frame Active
4		In2-	Encoder Source B\, Fame Start\, Frame Active\
5	GND (Signals)		Signals Ground
6	Line 3	In3+/Out3+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7		In3-/Out3-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output3-
8	Line 4	In4+/Out4+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+, MS-In+
9		In4-/Out4-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output4-, MS-In-
10	GND (PWR)		Camera Power Ground
11	Line 5	Out5+	User Output5+, MS-Out+
12		Out5-	User Output5-, MS-Out-
13	Line 6	Out6+	User Output6+
14		Out6-	User Output6-
15	Vcc (PWR)		Camera Power DC +12 V – +24 V








## Single-Ended (SE) configuration

The input threshold voltage can be configured globally to 3.3 V, 5 V, 12 V and 24 V. The Maximum input voltage is 28 V.

Pin	Line definition for Single-Ended configuration	Signal Single-Ended	Configuration proposal
1	Line 1	In1 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source A, Line Start
2	--	--	--
3	Line 2	In2 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source B, Fame Start, Frame Active
4	--	--	--
5	GND (Signals)		Signals Ground
6	Line 3	In3 (3.3 V, 5 V, 12 V, 24 V) Out3 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7	--	--	--
8	Line 4	In4 (3.3 V, 5 V, 12 V, 24 V) Out4 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+
9	--	--	--
10	GND (PWR)		Camera Power Ground

11	Line 5	In5 (3.3 V) Out5 (3.3 V)	LED Flash Out 3, User Output5
12	Line 7	In7 (3.3 V) Out7 (3.3 V)	LED Flash Out 2, User Output7
13	Line 6	In6 (3.3 V) Out6 (3.3 V)	LED Flash Out 0, User Output6
14	Line 8	In8 (3.3 V) Out8 (3.3 V)	LED Flash Out 1, User Output8
15	Vcc (PWR)		Camera Power DC +12 V – +24 V

## LED status indicator

Color code	Behaviour	Description
	Off	No power supply or the <a href="#">input voltage</a> is out of range.
	Blue continuous	The device is OK and provides image data.
	Green continuous	The device is in power-up mode.
	Green blinking	The device is OK and ready.
	Green/Blue alternative	The device is OK and provides image data frequently, based on a trigger signal.
	Yellow continuous	<a href="#">Warning-state</a> : The device is operational.
	Red continuous	<a href="#">Error-state</a> : The device is not operational.


# allPIXA neo 6k CXP

## Camera specifications

Sensor	CMOS
Pixel size	5 $\mu\text{m}$ $\times$ 5 $\mu\text{m}$
Line spacing	5 $\mu\text{m}$ between R-G & G-B & B-M, for NIR 195 $\mu\text{m}$ between NIR-R
Spectral sensitivity	400 nm – 960 nm
Resolution	6144 $\times$ 4 lines
Video output	2 $\times$ CoaXPress 2.0
Data format	3 $\times$ 8/10/12 Bit color or 1 $\times$ 8/10/12 Bit mono or 4 $\times$ 8/10/12 RGB + Mono
Trigger Mode	Frame Start / Frame Active / Frame Burst Start / Line Start / External Encoder
Video output port	2 $\times$ CXP-12 Micro-BNC
Digital I/O port	External I/O (15 pin HD D-Sub, male)
Power supply	PoC (Power over CoaXPress) or digital I/O port: 12 – 24V DC $\pm$ 10 %
Debugging port	-
Lens mount / adapter	M42 $\times$ 1 mm / F-Mount, TFL
Housing dimensions	62 mm $\times$ 62 mm $\times$ 62 mm
Weight	0,35 kg
Temperature during operation	0 $^{\circ}\text{C}$ – 60 $^{\circ}\text{C}$ ; 32 $^{\circ}\text{F}$ – 140 $^{\circ}\text{F}$
Humidity during operation	20 % – 85 % relative air humidity, non condensing
Temperature during transport and storage	-20 $^{\circ}\text{C}$ – +85 $^{\circ}\text{C}$ ; -4 $^{\circ}\text{F}$ – +185 $^{\circ}\text{F}$
Protection category	IP50
Certifications	CE, RoHS
General ambient conditions	
Transport	IEC 721-3-3:IE33
Operation	IEC 721-3-3:IE21
Storage	IEC 721-3-3:IE11


## Line scan sensor

## Sensor pixel arrangement




Left: Sensor line spacing and pixel arrangement of the 6k sensor  
 Right: Sensor line spacing and pixel arrangement of the 6k sensor with NIR

### Spectral sensitivity




Measured relative sensitivity of the color and the mono sensor




Measured relative spectral sensitivity of the 6k sensor with NIR

### Sensor alignment and orientation




Alignment and orientation of the 6k sensor: Color + Mono



Alignment and orientation of the 6k sensor: Color + NIR

## Mechanical dimensions




Dimensional drawing of the allPIXA neo 4k/6k CXP

[Download as pdf-file](#)

[Download dimensional drawing of the allPIXA neo 4k/6k CXP](#)

## Interface specification





<b>1</b>	Video output port (2 × CoaXPress 2.0) and power supply	<b>2</b>	Digital I/O port and power supply
<b>3</b>	Connector for additional fan	<b>4</b>	Status LED

### Line rate

Configuration (8 bit)	Line rate
Mono	240 kHz
RGB	80 kHz
RGB + Mono (NIR)	60 kHz


### Power supply

You can either use Power over CoaXPress (PoC) or the power supply of the external digital I/O port.

### Digital I/O port

The following connector is required for the digital I/O port:

- 15 pin HD D-Sub (female)



Pin allocation D-Sub connector (male) of the camera

You can configure the digital I/O port as RS422 or as single-ended input or output. It is also possible to configure one output as RS422 and the other output as single-ended.

## RS422 configuration

Pin	Line definition for RS422 configuration	Signal RS422	Configuration proposal
1	Line 1	In1+	Encoder Source A, Line Start
2		In1-	Encoder Source A\, Line Start\
3	Line 2	In2+	Encoder Source B, Fame Start, Frame Active
4		In2-	Encoder Source B\, Fame Start\, Frame Active\
5	GND (Signals)		Signals Ground
6	Line 3	In3+/Out3+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7		In3-/Out3-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output3-
8	Line 4	In4+/Out4+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+, MS-In+
9		In4-/Out4-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output4-, MS-In-
10	GND (PWR)		Camera Power Ground
11	Line 5	Out5+	User Output5+, MS-Out+
12		Out5-	User Output5-, MS-Out-
13	Line 6	Out6+	User Output6+
14		Out6-	User Output6-
15	Vcc (PWR)		Camera Power DC +12 V – +24 V

## Single-Ended (SE) configuration






The input threshold voltage can be configured globally to 3.3 V, 5 V, 12 V and 24 V. The Maximum input voltage is 28 V.

Pin	Line definition for Single-Ended configuration	Signal Single-Ended	Configuration proposal
1	Line 1	In1 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source A, Line Start
2	--	--	--
3	Line 2	In2 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source B, Fame Start, Frame Active
4	--	--	--
5	GND (Signals)		Signals Ground
6	Line 3	In3 (3.3 V, 5 V, 12 V, 24 V) Out3 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7	--	--	--
8	Line 4	In4 (3.3 V, 5 V, 12 V, 24 V) Out4 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+
9	--	--	--
10	GND (PWR)		Camera Power Ground

11	Line 5	In5 (3.3 V) Out5 (3.3 V)	LED Flash Out 3, User Output5
12	Line 7	In7 (3.3 V) Out7 (3.3 V)	LED Flash Out 2, User Output7
13	Line 6	In6 (3.3 V) Out6 (3.3 V)	LED Flash Out 0, User Output6
14	Line 8	In8 (3.3 V) Out8 (3.3 V)	LED Flash Out 1, User Output8
15	Vcc (PWR)		Camera Power DC +12 V – +24 V

## LED status indicator

Color code	Behaviour	Description
	Off	No power supply or the <a href="#">input voltage</a> is out of range.
	Solid orange	The system is booting.
	Flash_1_1red	The device is powered but not connected (not applicable to a device reliant on PoCXP power).
	AlternateFlash_12_5 green/orange; shown for a minimum of 1s even if connection detection is faster	The Connection detection is in progress, PoCXP is active.
	Flash_12_5 orange; shown for a minimum of 1s even if connection detection is faster	The Connection detection is in progress, PoCXP is not in use.
	AlternateFlash_0_5 red/green	The device/host is incompatible, PoCXP is active.
	AlternateFlash_0_5 red/orange	The device/host is incompatible, PoCXP is not in use.
	Solid red	PoCXP is over-current (host only).
	Solid green	The device/host is connected, but no data is transferred.
	Flash_1_ orange	The device/host is connected, waiting for event (e.g. trigger).

	Flash_12_5 green	The device/host is connected, data is being transferred.
	500ms red pulse	Error during data transfer (e.g. CRC error, single-bit error) is detected. In case of multiple errors, there shall be at least two green Flash_12_5 pulses, before the next error is indicated.
	AlternateFlash_0_5 green/orange	A connection test packet is being sent.
	AlternateFlash_0_5 red/green/orange	The compliance test mode is enabled (device only).
	Flash_12_5 red	A system error (e.g. internal error) occurred.

## Unboxing

Check your device upon delivery to ensure that it is undamaged and complete.

### **The packaging includes the following items:**

- Camera
- Information sheet

### **Additionally ordered and supplied accessories**

- Lens adapters, extension rings, lenses, and other accessories are not included in the standard scope of delivery. These items must be ordered separately as accessories.
- Check additionally ordered accessories for completeness and for damage, which may have occurred during transport.

## Mechanical installation

	<b>WARNING</b>
	<b>During lifting and setting down the device can fall and lead to injuries.</b>
	Use foot protection.

### Prepare the camera and lens

1. Select the correct lens and accessories to operate your camera in the desired environment.
2. Install the lens and adapters. For a detailed description of lens and mount installation, follow the [Chromasens Camera Configurator](#).
3. Mount the optional cooling kit if necessary.

### Thermal link and cooling

The camera operates within the defined housing temperature range of . If this range is exceeded, use cooling kits.

For more information on cooling kits and fans, see [Cooling kits and fans \(heat sink\)](#).

### Adjust and install your illumination

It is recommended to use a Chromasens Corona II illumination.


Follow the instructions of the Corona II manual for correct installation.

**Download**

<https://chromasens.de/de/corona-downloads>

### Install the camera in your system

Adjust the sensor line horizontally to the transport direction. The camera has to look perpendicular to the inspection area. For a detailed description of the correct camera installation, please check the following chapter.




## Mounting

The camera housing provides various mounting options. For information about the exact mechanical dimensions refer to [specification of your camera model](#).


## Conveyor belt tracking

The conveyor belt on which the object is transported must run absolutely straight as shown in the following graphic. Misalignment can cause image artifacts.



## Perpendicularity of the sensor to the direction of transport

Align the camera at a right angle (perpendicularly) to the transport direction as shown in the following graphic. Misalignment can cause chromatic aberration in the image.




## Rotation around the longitudinal axis of the sensor

### NOTE

If you are willing to use this installation method please contact [chromasens support](#) for further information.


Make sure that the longitudinal axis of the camera is parallel to the transport direction as shown in the following graphic. Misalignment can cause scale change and chromatic aberration in the image.





### Rotation around the transverse axis of the sensor

The transverse axis of the camera must run parallel to the transport direction as shown in the following graphic. Misalignment can cause scale change and chromatic aberration in the image.



## Electrical installation

### GigE interface

The 10 GigE connectors permit to use (direct attach) copper cables with lengths of up to 30 m (10BASE-T). A cable with the minimum specification of CAT6a must be used.

### Network adapter

To establish a 10 GigE connection a network adapter with a 10 GigE RJ45 input must be installed and configured on the PC. The installation of the network adapter is explained in the GCT documentation. For more information, see [Installation GigE](#).

For more information about the tested network adapters and the transceivers, see [Tested Network adapters and Transceivers](#).

### Cabling

<b>WARNING</b>
<b>Electric shock due to improper connection to a power supply.</b>
Use a 12 V – 24 V DC power supply. When using the digital I/O port as a power supply ensure the correct polarity.

1. Connect the video output port.
2. Connect the digital I/O port.

### Option 1: Power over Ethernet (PoE)

1. Plug the Ethernet cable into the Power/PoE port (PoEOUT) of the PoE injector and into the video output port (RJ45) of your camera.
2. Connect another Ethernet cable to the Ethernet/data (DataIN) port of the injector and your network card.

### Option 2: Power supply of the digital I/O port

To set up the wiring refer to section [Digital I/O port](#).

Note the permitted input voltages:

	Nominal	Minimum	Maximum
Permitted voltages	24 V	12 V	28 V

### CXP interface

The interface allows you to connect two CXP cables. Micro BNC (for CXP12) connectors for the camera and suitable connectors for the frame grabber are required. The maximum cable length is 35 m.

## Frame grabber

To establish a CXP connection a frame grabber must be installed and configured on the PC. Refer to the manual of your frame grabber.

For more information about the tested frame grabbers, see [Tested frame grabbers](#).

## Cabling

<b>WARNING</b>
<p><b>Electric shock due to improper connection to a power supply.</b></p> <p>Use a 12 V – 24 V DC power supply. When using the digital I/O port as a power supply ensure the correct polarity.</p>

1. Connect the video output port.
2. Connect the digital I/O port.

### Option 1: Power over CoaXPress (PoC)

To use the power-over-CXP function two connections are needed.

### Option 2: Power supply of the digital I/O port

To set up the wiring refer to section [Digital I/O port](#).


Note the permitted input voltages:

	Nominal	Minimum	Maximum
Permitted voltages	24 V	12 V	28 V

## Digital I/O port

The following connector is required for the digital I/O port:

- 15 pin HD D-Sub (female)



Pin allocation D-Sub connector (male) of the camera

You can configure the digital I/O port as RS422 or as single-ended input or output. It is also possible to configure one output as RS422 and the other output as single-ended.

### RS422 configuration

Pin	Line definition for RS422 configuration	Signal RS422	Configuration proposal

1	Line 1	In1+	Encoder Source A, Line Start
2		In1-	Encoder Source A\, Line Start\
3	Line 2	In2+	Encoder Source B, Fame Start, Frame Active
4		In2-	Encoder Source B\, Fame Start\, Frame Active\
5	GND (Signals)		Signals Ground
6	Line 3	In3+/Out3+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7		In3-/Out3-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output3-
8	Line 4	In4+/Out4+	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+, MS-In+
9		In4-/Out4-	Encoder Source A\, Fame Start\, Frame Active\, Line Start\, User Output4-, MS-In-
10	GND (PWR)		Camera Power Ground
11	Line 5	Out5+	User Output5+, MS-Out+
12		Out5-	User Output5-, MS-Out-
13	Line 6	Out6+	User Output6+
14		Out6-	User Output6-
15	Vcc (PWR)		Camera Power DC +12 V – +24 V

### Single-Ended (SE) configuration

The input threshold voltage can be configured globally to 3.3 V, 5 V, 12 V and 24 V. The Maximum input voltage is 28 V.

Pin	Line definition for Single-Ended configuration	Signal Single-Ended	Configuration proposal
1	Line 1	In1 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source A, Line Start
2	--	--	--
3	Line 2	In2 (3.3 V, 5 V, 12 V, 24 V)	Encoder Source B, Fame Start, Frame Active
4	--	--	--
5	GND (Signals)		Signals Ground
6	Line 3	In3 (3.3 V, 5 V, 12 V, 24 V) Out3 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output3+
7	--	--	--
8	Line 4	In4 (3.3 V, 5 V, 12 V, 24 V) Out4 (3.3 V)	Encoder Source A, Fame Start, Frame Active, Line Start, User Output4+
9	--	--	--
10	GND (PWR)		Camera Power Ground
11	Line 5	In5 (3.3 V) Out5 (3.3 V)	LED Flash Out 3, User Output5
12	Line 7	In7 (3.3 V) Out7 (3.3 V)	LED Flash Out 2, User Output7

13	Line 6	In6 (3.3 V) Out6 (3.3 V)	LED Flash Out 0, User Output6
14	Line 8	In8 (3.3 V) Out8 (3.3 V)	LED Flash Out 1, User Output8
15	Vcc (PWR)		Camera Power DC +12 V – +24 V


## Configure the I/O's

The IO Ports can be configured in GCT.

1. Connect and open the camera in GCT	
2. Navigate to <i>Camera Features, Digital IO Control</i>	
3. Select the Line in the <i>Line Selector</i>	
4. Open the Drop-down menu and change the <b>Line Format</b>	


## Circuit Diagrams

### RS422 configuration




External circuit: RS422 device

### Single-Ended configuration



External circuit: Optocoupler



External circuit: TTL or CMOS logic gate

## Software installation and configuration

We recommend using the Chromasens GCT tool to acquire the first images. For information about the installation and use of GCT, refer to the [GCT documentation](#).

1. Connect your camera to the PC.
2. Turn on the camera.

The installation and configuration of your PC are described in the [GCT documentation](#).

## Starter-Kit


The Starter-Kit for allPIXA neo provides all relevant components to set up a test system, acquire the first images, and evaluate the camera. This instruction helps you to acquire the first images in your development environment.

## Unboxing

The Starter-Kit provides the following components:

Part Number	Quantity	Description
CP000660-X-X-X	1	allPIXA neo line scan camera
CC03304	1	Network card, BroadcomP210TP - 2 x 10GBASE-T PCIe NIC
CP000722-X	1	Trigger cable
CC03336	2	Ethernet cable Cat6a
CC03335	1	Power over Ethernet Injector (PoE Injector)
CP000662	1	allPIXA neo F-Mount adapter
CP000667	1	allPIXA neo Fan Cooling

## Getting Started

1. Unpack the camera and the components	
2. Install the network card into your computer	
3. Download and install the drivers of your network card	<a href="#">Network adapters and transceivers</a>
4. Connect the camera with the PoE injector and the PC	<p><b>Note</b></p> <p>It must be ensured that the camera does not become too hot. Therefore, it should be operated with a cooler or in an environment that dissipates the heat.</p> <p><a href="#">Electrical installation</a></p>
5. Install GCT	<a href="#">Installation GigE</a>
6. Acquire the first image	<a href="#">Acquire the first image</a>

## Further Steps

1. Install the camera in your system	<a href="#">Mechanical installation</a>
2. Setup your Trigger	<a href="#">Electrical installation</a>



3. Perform the camera image calibration steps

[Camera image calibration](#)


# Acquire the first image

## Connect the camera

<ol style="list-style-type: none"> <li>1. Open GCT2.</li> <li>2. Click on the <b>magnifying glass icon</b>.</li> </ol>					
<ol style="list-style-type: none"> <li>3. In the Discovery window click <b>Start Discovery</b>.</li> <li>4. Select your camera and click <b>Open</b>.</li> </ol>	<table border="1" data-bbox="662 1187 1364 1545"> <thead> <tr> <th>Transport Layer and its Device</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> <li>Euresys Coaxlink (EuresysCoaxlink)                             <ul style="list-style-type: none"> <li>Chromasens GmbH allPIXAevo 15K RGB C... SN:40230-02148</li> </ul> </li> <li>S2I GEV TL Interface                             <ul style="list-style-type: none"> <li>Chromasens GmbH:allPIXAevo 8K RGB DX... SN:40203-02105</li> </ul> </li> </ul> </td> <td> <ul style="list-style-type: none"> <li>C:\Program Files\Euresys\eGrabbe...</li> <li>C:\Program Files\Chromasens\GC...</li> </ul> </td> </tr> </tbody> </table>	Transport Layer and its Device	Description	<ul style="list-style-type: none"> <li>Euresys Coaxlink (EuresysCoaxlink)                             <ul style="list-style-type: none"> <li>Chromasens GmbH allPIXAevo 15K RGB C... SN:40230-02148</li> </ul> </li> <li>S2I GEV TL Interface                             <ul style="list-style-type: none"> <li>Chromasens GmbH:allPIXAevo 8K RGB DX... SN:40203-02105</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>C:\Program Files\Euresys\eGrabbe...</li> <li>C:\Program Files\Chromasens\GC...</li> </ul>
Transport Layer and its Device	Description				
<ul style="list-style-type: none"> <li>Euresys Coaxlink (EuresysCoaxlink)                             <ul style="list-style-type: none"> <li>Chromasens GmbH allPIXAevo 15K RGB C... SN:40230-02148</li> </ul> </li> <li>S2I GEV TL Interface                             <ul style="list-style-type: none"> <li>Chromasens GmbH:allPIXAevo 8K RGB DX... SN:40203-02105</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>C:\Program Files\Euresys\eGrabbe...</li> <li>C:\Program Files\Chromasens\GC...</li> </ul>				


## Load the default user set

1. In the Configuration window navigate to *Special Functions* → *User Set Control*.
2. Click **Load**.



## Acquire an image

Click on the **camera sign** to acquire the first image.




## Video description

## Acquire a test pattern


### Load the default user set

1. In the Configuration window navigate to *Special Functions* → *User Set Control*.
2. Click **Load**.



### Generate a test pattern

1. In the Configuration window navigate to *Special Functions* → *Test Pattern Generator*.
2. Select the **Enable** checkbox.



### Compare the template to the generated image

1. Acquire an image.
2. Compare the template to the generated image.
3. Disable the test pattern if it matches with the generated image.

## Video description

# Acquire images with frame and line trigger

## Setup the frame trigger

1. In the Configuration window navigate to *Acquisition Control* → *Frame Trigger*.
2. Setup the frame trigger.

Refer to [Set a frame trigger](#).

The screenshot displays the 'Frame Trigger' configuration window in the Chromasens software. The 'External' section is selected, indicating that an external source will generate the frame trigger. The configuration includes the following settings:

- Signal type:** Single-ended (LVCMOS)
- Input signal source:** Line 3 - IO pin 3
- Input signal activation:** Frame start at rising edge
- Number of lines to delay frame trigger signal / Y-offset:** 0
- Number of lines to extend frame-active signal:** 0

The 'Wiring' diagram shows a switch connected to 'Line 3', which is plugged into the 'Camera interface'. The 'Signal diagram' illustrates the timing of the frame trigger signal. It shows a square wave pulse with a rising edge and a falling edge. The rising edge is labeled 'Signal type: rising edge' and the falling edge is labeled 'Signal type: falling edge'. The diagram also shows the 'Integration time' and 'Image height' for both signal types, with a 'Frame-trigger delay' indicated between the rising edge and the start of the integration time.

## Setup the line trigger

1. In the Configuration window navigate to *Acquisition Control* → *Line Trigger*.
2. Setup the line trigger.
3. Acquire an image.

Check your cabling if you do not receive an image.  
Refer to [Set a line trigger](#).

The screenshot shows the 'Line Trigger' configuration window in the Chromasens software. The 'External - Encoder signal' option is selected. The settings are as follows:

- Encoder channels: 2
- Encoder signal type: Differential (RS422)
- Encoder Input channel A: Line1 - IO Pin 1,6
- Encoder Input channel B: Line2 - IO Pin 2,7
- Encoder direction: Clockwise
- Amount of encoder pulses to generate one line trigger: 1,0000

The 'Signal diagram' section shows the encoder wiring and the resulting signals. It includes a diagram of the encoder with two channels, Line 1 (A/A) and Line 2 (B/B), connected to the camera. The signal diagram shows the differential signals for Line 1 and Line 2, with a red box indicating the number of encoder pulses to average. Below this, the 'Line trigger' and 'Exposure-time' signals are shown as square waves, with the 'Line time' interval marked.

## Introduction

To ensure a correct image calibration follow the articles in order.

Begin with *Perform white balancing* and end with *Check the image quality*.



## Perform white balancing

The adjustment of a camera system is an iterative process. It might be necessary to do the white balancing step twice.

**NOTE: The white reference must be clean and in the focusing plane of the camera.**

Use a professional white reference, e.g. a clean white ceramic or plastic material.

For the best result use a moving white reference to diminish the effects on any optical variations in the white reference.

### Prepare your system

1. Place a white reference under the camera.
2. Set the lens aperture f-stop on the camera lens.
3. [Load the default user set.](#)
4. Set the maximum [exposure time.](#)
5. Set the [line time.](#)
6. Switch on the illumination and set the light current.


#### Deactivate DSNU and PRNU correction

7. In the Configuration window navigate to *Camera Image Calibration* → *DSNU/PRNU*.
8. Select the **Deactivate DSNU correction** checkbox.
9. Select **Deactivate PRNU correction** checkbox.

The screenshot shows the 'DSNU/PRNU' configuration window. It has two main sections: 'DSNU (Dark Signal Non Uniformity) correction' and 'PRNU (Photo Response Non Uniformity) correction'. Both sections have a radio button for 'Deactivate' correction, which is selected. Below each section, there are two options for look-up tables (LUTs) with text input fields for their names and 'Upload' buttons. In the DSNU section, the first LUT is named 'SENS BREF DATASET 1' and the second is 'Setting 0x01'. In the PRNU section, the first LUT is named 'SENS SHC DATASET 1' and the second is 'internal PRNU LUT2'. There are also 'Generate' buttons for each section.

### Configure the gain settings

1. Click on the **plus sign** in the right window to add a new tab.
2. Select **Horizontal Line Plot**.



3. In the Configuration window navigate to *Camera Image Calibration* → *Gain*.

The current values in the 10 bit range are displayed.

Current Values in 10 bit range			
Red	Green	Blue	Infrared
648	468	305	0



4. Select the **Enable** checkbox in *Automatic gain control settings*.
5. Set the reference mark position and size: Below *ROI for automatic gain control* set the values for **Offset X, Offset Y, Width** and **Height**.

**HINT**  
To control the position in images you can temporarily select the **Visible feature**.

6. Make sure that the reference mark position is at the brightest region of the image (at the center).
7. Set the target white reference values: Below *Target values in 10 bit range* set the values for **Red, Green, Blue** and **Infrared**.

**NOTE**  
The target values should be between 800 – 880 to get values between 200 – 220 in the horizontal line plot.

8. Click on **Once** in *Automatic gain control settings*.



The camera performs a white balancing with the current settings.

After successful balancing *Gain Auto Status* returns **Control Successful**.


If an error occurs [modify the sensor sensitivity](#).

**NOTE: Repeat the white balancing in the following cases**

If you change the f-stop of the camera lens or the setting of the illumination repeat the white balancing.

## Adjust the lens

1. Place a line pattern target under the camera.
2. Acquire an image which looks like this.




3. Click on the **plus sign** in the right window to add a new tab.
4. Select **Histogram**.


The values are spread between 60 – 170 DN.



Adjust the lens to achieve the values spread in the whole spectrum.





The image of the line pattern has a high contrast.





# Create a black-reference (DSNU)

Create a black-reference with DSNU.

<ol style="list-style-type: none"> <li>1. Switch off the illumination.</li> <li>2. Cover the lens with a black or dark piece of cardboard or plastic. No light may reach the sensor.</li> </ol>	
<ol style="list-style-type: none"> <li>3. In the <i>menu bar</i> navigate to <i>Tools</i> → <i>Calibration</i>.</li> <li>4. Click <b>Generate DSNU Reference</b>.</li> </ol>	
<p>The <i>Generate DSNU Reference</i> wizard opens.</p> <ol style="list-style-type: none"> <li>5. Click <b>Acquire image</b> to generate the DSNU directly from the camera <b>or</b> click <b>Load from Disk</b> to load an image from the hard drive.</li> </ol> <div style="background-color: #e0f2f1; padding: 10px; margin-top: 10px;"> <p><b>NOTE: Load from Disk</b> Make sure that the image has been taken with active image calibration mode by using the wizard.</p> </div> <p>The raw image and the line plot of the image is displayed.</p> <p>Send the calculated DSNU to the camera:</p> <ol style="list-style-type: none"> <li>6. Select <b>LUT 1</b> or <b>LUT 2</b>.</li> <li>7. Click <b>Send data to camera</b>.</li> </ol>	

8. In the Configuration window navigate to *Camera Image Calibration* → *DSNU/PRNU*.
9. Make sure that DSNU is enabled.

The screenshot shows the configuration window for DSNU and PRNU corrections. The window is titled 'DSNU (Dark Signal Non Uniformity) correction' and 'PRNU (Photo Response Non Uniformity) correction'. It contains two sections: DSNU and PRNU. Each section has a radio button to deactivate the correction, two radio buttons for look-up tables, text input fields for dataset names, and 'Upload' and 'Generate' buttons.

**DSNU (Dark Signal Non Uniformity) correction**

- Deactivate DSNU correction
- DSNU look-up table 1: Dataset Name: SENS BREF DATASET 1, Upload DSNU data-set
- DSNU look-up table 2: Dataset Name: Setting 0x01, Upload DSNU data-set
- Generate DSNU data-set

**PRNU (Photo Response Non Uniformity) correction**

- Deactivate PRNU correction
- PRNU look-up table 1: Dataset Name: SENS SHC DATASET 1, Upload PRNU data-set
- PRNU look-up table 2: Dataset Name: internal PRNU LUT2, Upload PRNU data-set
- Generate PRNU data-set



## Create a shading-reference (PRNU)

### Standard PRNU reference generating

Create a shading-reference with PRNU.

1. Place a moving white target.  
If using a stationary target, place it slightly out of focus.

Acquire an image:

2. In the toolbar click **Acquire a single frame** or click **Start grabbing**, wait until an image is displayed, click **Stop grabbing**.

3. In the *menu bar* navigate to *Tools* → *Calibration*.
4. Click **Generate PRNU Reference**.



The *Generate PRNU Reference* wizard opens.

5. Click **Acquire image** to generate the PRNU directly from the camera  
**or**  
 click **Load from Disk** to load an image from the hard drive.

**NOTE: Load from Disk**  
 Make sure that the image has been taken with active image calibration mode by using the wizard.

The raw image and the line plot of the image is displayed.


6. Click **Start 2-Click-Selection**.
7. Click **on the image** to select the ROI.

Send the calculated PRNU to the camera:

8. Select **LUT 1** or **LUT 2**.
9. Click **Send data to camera**.

Activate brightness and contrast:


10. Select the **Activate Brightness and contrast** checkbox.
11. Set the **Contrast** to 0.9.




## Extrapolation function

If the white reference does not cover the entire FOV, the extrapolation function can be used to generate it. In this case, a straight line is fitted to the gradient. Therefore follow the description below.


On the right side, you can see the *raw image* and the *Applied PRNU reference* without the extrapolation function. In the area with low image content, the *Applied PRNU reference* shows some artifacts.



1. Select the ROI, by using the **Start-2-Click-Selection**.
2. *Press* the button with the three dots on the bottom.
3. *Enable* your option, in this example the **Left** extrapolation.
4. Select the *Start* position of your extrapolation. The *width* defines the area where the extrapolation is created. From the *Start* position to column 0, the extrapolation is applied.




5. Check the applied PRNU in the *Applied PRNU reference* tab.








## Save the setting

1. In the Configuration window navigate to *Special Functions* → *User Set Control*.
2. In *Save current setting to User Set* choose **User Set 1**.
3. Click **Save**.



## Check the image quality


<ol style="list-style-type: none"> <li>1. Place an image target under the camera, e.g. a colorchecker classic.</li> <li>2. Acquire an image.</li> <li>3. Analyze the image: If the image is covered with vertical stripes you may have not used a <b>moving shading reference</b>.</li> </ol>	
<ol style="list-style-type: none"> <li>4. If the image has color shifts check the <b>scan direction</b>.</li> </ol>	
<ol style="list-style-type: none"> <li>5. If the image is compressed in transport direction adapt the <b>encoder divider float value</b> or <b>the acquisition line rate</b>.</li> </ol>	
<ol style="list-style-type: none"> <li>6. If the image is shown mirror-inverted, use the <b>ReverseX parameter</b>.</li> </ol>	
<p>This is an example of a good image quality.</p>	

## Set a frame trigger

### Internal frame trigger

The internal frame trigger provides a continuous signal after each acquired image.

1. In the Configuration window navigate to *Acquisition Control* → *Frame Trigger*.
2. Below *Internal* select the **Generate frame trigger continuously after each acquired image** checkbox.



Internal frame trigger

Alternatively, you can set the internal frame trigger in the **camera feature tree** by executing the following steps:

Step	Feature name	Value
1	Trigger Selector	FrameActive
2	Trigger Mode	Off
3	Trigger Selector	FrameStart
4	Trigger Mode	Off
5	Trigger Selector	LineStart
6	Trigger Mode	Off

### External frame trigger

The external frame trigger can be provided by a light barrier.

1. In the Configuration window navigate to *Acquisition Control* → *Frame Trigger*.
2. Below *External* select the **Use external source to generate frame trigger** checkbox.

### Signal type

#### Single-ended (LVCMOS)

1. In *Signal type* select **Single-ended (LVCMOS)**.

The single-ended frame trigger configuration is done on line 3 and line 4.

2. In *Input signal activation* select the desired trigger activation mode. Refer to [Input signal activation](#).

External

Use external source to generate frame trigger

Signal type: Single-ended (LVCMOS)

Input signal source: Line 3 - IO pin 3

Input signal activation: Frame start at rising edge

Number of lines to delay frame trigger signal / Y-offset: 0

Number of lines to extend frame-active signal: 0

Alternatively, you can set the single-ended external frame trigger in the **camera feature tree** by executing the following steps:

Step	Feature name	Value
1	TriggerSelector	FrameStart, FrameActive or FrameBurstStart
	TriggerMode	On
2	TriggerSource	e.g. Line 3 <b>or</b> Line 4
3	TriggerActivation	Level high/level low, rising edge <b>or</b> falling edge
4	TriggerDelayLines	<number of lines>
5	TriggerSignalDetectionMode	Peakholder Detection, Debouncing 4 clocks, Debouncing 4 lines, Debouncing 60 lines

## Differential (RS422)

1. In *Signal type* select **Differential (RS422)**.

The differential frame trigger configuration is done on line 2.

2. In *Input signal activation* select the desired trigger activation mode. Refer to [Input signal activation](#).

Alternatively, you can set the differential external frame trigger in the **camera feature tree** by executing the following steps:


Step	Feature name	Value
1	TriggerSelector	FrameStart, FrameActive or FrameBurstStart
	TriggerMode	On
2	TriggerSource	e.g. Line 2
3	TriggerActivation	Level high <b>or</b> level low, rising edge <b>or</b> falling edge
4	TriggerDelayLines	<number of lines>
5	TriggerSignalDetectionMode	Peakholder Detection, Debouncing 4 clocks, Debouncing 4 lines, Debouncing 60 lines

## Input signal activation

### Frame start

The *Input signal activation* → *Frame start* triggers the image acquisition after the *Trigger delay lines* and depending on the *Trigger signal detection mode* configuration for the duration of the image height setting. One frame trigger creates one image with a constant image height.






## Frame active

### Note

This configuration is only for the GigE Version available. CxP does not support this configuration.

The *Input signal activation* → *Frame active* triggers the image acquisition after the *Trigger delay lines* and depending on the *Trigger signal detection mode* configuration for the duration of the Trigger signal. One Frame trigger creates one image with the length of the frame active signal.




## Frame burst start

### Note

In *Frame burst start* mode the camera acquires multiple gapless images.

The *Input signal activation* → *Frame burst start* triggers the image acquisition after the *Trigger delay lines* and depending on the *Trigger signal detection mode* configuration for multiple times the duration of the image height setting. One frame burst creates multiple images with a constant image height.

The number of acquired images is set under *Acquisition Control* → *Acquisition Burst Frame Count*.




## Trigger signal detection mode

The camera supports four different Trigger signal detection modes. This configuration parameter defines the signal debouncing of the frame trigger input signal.

To set the *Trigger signal detection* navigate to the **camera feature tree** → **Acquisition control** → **Trigger selector** the following four options are available:


### PeakholderDetection

The *Trigger signal detection mode* → *PeakholderDetection* detects every small input signal and starts the image acquisition immediately.




### Debouncing4Lines

The *Trigger signal detection mode* → *Debouncing4Lines* requires a 4 line stable trigger input signal, this leads to an image delay of 4 lines.




### Debouncing60Lines

The *Trigger signal detection mode* → *Debouncing60Lines* requires a 60 line stable trigger input signal, leading to an image delay of 60 lines.



### **Debouncing4Clocks (not recommended)**

The *Trigger signal detection mode* → *Debouncing4Clocks* requires a 4 clocks (clks) stable trigger input signal, leading to an image delay of 4 clocks.




## Set a line trigger

### Internal line trigger

The internal line trigger provides a continuous signal in the frequency of the exposure time.

1. In the Configuration window navigate to *Acquisition Control* → *Line Trigger*.
2. Below *Internal* select the **Generate line trigger at frequency of line rate** checkbox.



Alternatively you can set the internal line trigger in the **camera feature tree** by executing the following step:

Step	Feature name	Value
1	Trigger Selector	LineStart
	Trigger Mode	Off

### External line trigger

The external line trigger can be provided by an encoder signal.

1. In the Configuration window navigate to *Acquisition Control* → *Line Trigger*.
2. Below *External* select the **Generate line trigger from external encoder signal** checkbox.

### Signal type: Single-ended (LVCMOS)

1. In *Encoder signal type* select **Single-ended (LVCMOS)**.
2. In *Encoder Input channel A* select **Line3 – IO Pin 3**.

The single-ended line trigger configuration is done on line 3 and line 4.

External - Encoder signal

Generate line trigger from external encoder signal

Encoder channels: 1

Encoder signal type: Single-Ended (LVCMOS)

Encoder Input channel A: Line3 - IO Pin 3

Encoder Input channel B: Off

Encoder direction: Counter-Clockwise

Amount of encoder pulses to generate one line trigger: 1,0730

**Encoder wiring**

**Signal diagram**

Alternatively you can set the external single-ended line trigger in the **camera feature tree** by executing the following steps:

Step	Feature name	Value
1	TriggerSelector	LineStart
	TriggerMode	On
2	TriggerSource	Encoder0 <b>or</b> Line1 <b>or</b> Line3 <b>or</b> Line4
3	EncoderSelector	Encoder0
4	EncoderSource A	Line1
5	EncoderSource B	Line2
6	EncoderDividerFloat	0.05 – 255
7	Encoder	FourPhase

## Signal type: Differential (RS422)



1. In *Encoder signal type* select **Differential (RS422)**.
2. In *Encoder Input channel A* select **Line1 – IO Pin 1,6**.
3. In *Encoder Input channel B* select **Line2 – IO Pin 2,7**.

External - Encoder signal

Generate line trigger from external encoder signal

Encoder channels: 2

Encoder signal type: Differential (RS422)

Encoder Input channel A: Line1 - IO Pin 1,6

Encoder Input channel B: Line2 - IO Pin 2,7

Encoder direction: Clockwise

Amount of encoder pulses to generate one line trigger: 1,0730

**Encoder wiring**

**Signal diagram**

Alternatively you can set the external differential line trigger in the **camera feature tree** by executing the following steps:

Step	Feature name	Value
1	TriggerSelector	LineStart
	TriggerMode	On
2	TriggerSource	Encoder0 <b>or</b> Line1 <b>or</b> Line3 <b>or</b> Line4
3	EncoderSelector	Encoder0
4	EncoderSource A	Line1
5	EncoderSource B	Line2
6	EncoderDividerFloat	0.05 – 255
7	Encoder	FourPhase

An encoder typically does not have an integer ratio to the camera resolution. Arbitrary ratios of encoder pulses per sensor line are possible, for example 2.25. The value range is 0.05 – 255 pulses per line.

If the number of pulses per line is **greater than 255**:



1. In the Configuration window navigate to *Acquisition Control* → *Trigger Selector*.
2. Set *Trigger Divider* and *Encoder Divider Float* to the desired values.  
E.g. for 320 pulses per line set *Trigger Divider* to **2** and *Encoder Divider Float* to **160.0**.

### Configurations of the external line trigger

Trigger selector	Line start
Signal from the line trigger	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><b>Encoder wiring</b></p> </div> <div style="text-align: center;"> <p><b>Signal diagram</b></p> </div> </div>
Trigger source: Encoder 0	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><b>Encoder wiring</b></p> </div> <div style="text-align: center;"> <p><b>Signal diagram</b></p> </div> </div>
Trigger source: Line1, Line3, Line4	<p style="text-align: center;">Line trigger</p>

# Create a black-reference (DSNU)

Create a black-reference with DSNU.

<ol style="list-style-type: none"> <li>1. Switch off the illumination.</li> <li>2. Cover the lens with a black or dark piece of cardboard or plastic. No light may reach the sensor.</li> </ol>	
<ol style="list-style-type: none"> <li>3. In the <i>menu bar</i> navigate to <i>Tools</i> → <i>Calibration</i>.</li> <li>4. Click <b>Generate DSNU Reference</b>.</li> </ol>	
<p>The <i>Generate DSNU Reference</i> wizard opens.</p> <ol style="list-style-type: none"> <li>5. Click <b>Acquire image</b> to generate the DSNU directly from the camera  <b>or</b>  click <b>Load from Disk</b> to load an image from the hard drive.</li> </ol> <div style="background-color: #e0f2f7; padding: 10px; margin-top: 10px;"> <p><b>NOTE: Load from Disk</b>  Make sure that the image has been taken with active image calibration mode by using the wizard.</p> </div> <p>The raw image and the line plot of the image is displayed.</p> <p>Send the calculated DSNU to the camera:</p> <ol style="list-style-type: none"> <li>6. Select <b>LUT 1</b> or <b>LUT 2</b>.</li> <li>7. Click <b>Send data to camera</b>.</li> </ol>	

8. In the Configuration window navigate to *Camera Image Calibration* → *DSNU/PRNU*.
9. Make sure that DSNU is enabled.

The screenshot shows the configuration window for DSNU/PRNU correction. The window is titled 'DSNU (Dark Signal Non Uniformity) correction' and 'PRNU (Photo Response Non Uniformity) correction'. It contains two sections: DSNU and PRNU. Each section has a radio button to deactivate the correction, two radio buttons for look-up tables, input fields for dataset names, and 'Upload' and 'Generate' buttons.

**DSNU (Dark Signal Non Uniformity) correction**

- Deactivate DSNU correction
- DSNU look-up table 1: Dataset Name: SENS BREF DATASET 1, Upload DSNU data-set
- DSNU look-up table 2: Dataset Name: Setting 0x01, Upload DSNU data-set
- Generate DSNU data-set

**PRNU (Photo Response Non Uniformity) correction**

- Deactivate PRNU correction
- PRNU look-up table 1: Dataset Name: SENS SHC DATASET 1, Upload PRNU data-set
- PRNU look-up table 2: Dataset Name: internal PRNU LUT2, Upload PRNU data-set
- Generate PRNU data-set

## Create a shading-reference (PRNU)

### Standard PRNU reference generating

Create a shading-reference with PRNU.

1. Place a moving white target.  
If using a stationary target, place it slightly out of focus.

Acquire an image:

2. In the toolbar click **Acquire a single frame** or click **Start grabbing**, wait until an image is displayed, click **Stop grabbing**.

3. In the *menu bar* navigate to *Tools* → *Calibration*.
4. Click **Generate PRNU Reference**.



The *Generate PRNU Reference* wizard opens.

- Click **Acquire image** to generate the PRNU directly from the camera  
**or**  
 click **Load from Disk** to load an image from the hard drive.

**NOTE: Load from Disk**  
 Make sure that the image has been taken with active image calibration mode by using the wizard.

The raw image and the line plot of the image is displayed.


- Click **Start 2-Click-Selection**.
- Click **on the image** to select the ROI.

Send the calculated PRNU to the camera:

- Select **LUT 1** or **LUT 2**.
- Click **Send data to camera**.

Activate brightness and contrast:


- Select the **Activate Brightness and contrast** checkbox.
- Set the **Contrast** to 0.9.




## Extrapolation function

If the white reference does not cover the entire FOV, the extrapolation function can be used to generate it. In this case, a straight line is fitted to the gradient. Therefore follow the description below.


On the right side, you can see the *raw image* and the *Applied PRNU reference* without the extrapolation function. In the area with low image content, the *Applied PRNU reference* shows some artifacts.



1. Select the ROI, by using the **Start-2-Click-Selection**.
2. *Press* the button with the three dots on the bottom.
3. *Enable* your option, in this example the **Left** extrapolation.
4. Select the *Start* position of your extrapolation. The *width* defines the area where the extrapolation is created. From the *Start* position to column 0, the extrapolation is applied.



5. Check the applied PRNU in the *Applied PRNU reference* tab.



# Updating the firmware

<b>NOTICE</b>
<b>Irreparable damage to the camera</b>
If the camera is powered down during firmware update it may get into a non-functional state. Recovery may not be possible.

Update your firmware only to change camera functions or fix known bugs.

Any firmware update may not only add new features to a camera or fix known issues. It may also replace previous features or change camera characteristics. See firmware release notes for details.

<p>1. Download firmware from the Chromasens website or use the firmware file provided by Chromasens.</p>	
<p>2. Note the <b>Device Package Version</b> of the currently installed firmware displayed in the <i>Device Control feature group</i>.</p>	
<p>3. In the <i>menu bar</i> navigate to <i>Tools</i>.</p> <p>4. Click <b>Up-/Download</b> or use the hotkey <b>Ctrl+D</b>.</p>	



The *Update/Download* wizard opens.  
 4. Click **Select Update File** and select the *Firmware Package file* to upload and click **Open**.

**NOTE: Firmware Package file**

For allPIXA evo select the allPIXAevo\_listfile\_.....ini file.  
 For allPIXA neo select the allPIXAneo\_listfile\_.....ini file.

5. GCT shows a warning message.
6. Check if the *Update* field shows the *Firmware Package file* type.
7. Click **Start Update**.
8. GCT shows a warning message.
9. Click **Yes** to start the Upload.

**NOTE: Time for Update**





Depending on the file size, firmware upload may take up to several minutes.

10. Check the text in the Info Box: If the update was successful, it contains a green confirmation message "Update is successfully completed".

**NOTE: Update Status**

If the update was unsuccessful, do not switch off the camera, try to restore the previous state by uploading the correct file for the previously selected file type.

11. Reconnect and Restart the camera
12. Check the **Device Package Version** in the *Device Control feature* group to make sure that the camera successfully booted with the new firmware.



## Overview

### Release 1.0.0 - (November 2023)

Camera	New features
allPIXA neo 4k 10GigE Color	Init version
allPIXA neo 6k 10GigE Color	Init version
allPIXA neo 6k 10GigE Color - NIR	Init version

## Camera Firmware 1.0.0

### Feature Reference

The corresponding Feature reference to the camera firmware version 1.0.0 is version 6.3.0.

Your browser does not support PDF.click [here](#) to download

### Release Notes

Your browser does not support PDF.click [here](#) to download

## Troubleshooting

Status LED	Possible cause	Device error code	Action
It does <b>not</b> turn <b>green</b> immediately after switching on the power supply.	The fuse has been tripped due to an incorrect input voltage.	–	<ol style="list-style-type: none"> <li>1. Switch off the power supply.</li> <li>2. Contact <a href="#">service</a>.</li> </ol>
Yellow	The internal temperature is above the defined warning limit.	DEV_CTRL_WARNING_TEMPERATURE_TOO_HIGH	Decrease ambient temperature and improve cooling.
Red	The internal temperature has reached the defined error limit.	DEV_CTRL_ERROR_TEMPERATURE_TOO_HIGH	<p>The camera automatically switches to safety mode and indicates an image with a pin stripe test pattern on a black background.</p> <ol style="list-style-type: none"> <li>1. Switch off the power supply and let the camera cool down.</li> <li>2. Check the ambient conditions (0 °C – 60 °C; 32 °F – 140 °F) and improve cooling.</li> <li>3. Switch on the power supply.</li> </ol>

## Maintenance and disposal

### Safety instructions

- Only technicians of [Chromasens GmbH](#) are permitted to open or slacken screws or housing sections of the device.
- Before carrying out any work on the device disconnect the power supply.
- To avoid the risk of fire let other devices such as radiators, heaters or lightning equipment cool down first.
- Necessary repairs may only be carried out by [Chromasens GmbH](#).

<b>CAUTION</b>
<b>The device can heat up to 60 °C.</b>
Do not touch the hot surface. Let the device cool down before carrying out any work on it.

### Cleaning

During operation of the device, particles such as dust etc. may be settled on the lens. These deposits affect the quality of the optical image and the function of the device negatively.

### Cleaning intervals

Specify regular cleaning intervals depending on your ambient conditions and the degree of soiling.


### Cleaning procedure

1. Disconnect the power supply.
2. Let the device cool down. Wait at least 30 minutes.
3. Wipe all surfaces with a soft and lint-free cloth, starting with the lens. The use of isopropanol ist optional, refer to the manufacturer's manual.
4. Inspect the device to ensure that cleaning was effective and repeat if necessary.

### Repair

In case of damages to the device refer to [Chromasens GmbH](#).

### Disposal

	<p>This product is an electronic device. Please dispose this product in accordance with your local regulations. Contact your local government office for details about environmentally safe recycling.</p>
---	--

